


AIR DRILL AD-65B ASSEMBLY AND PARTS LIST



The Part Numbers with () are included in the Ass'y parts written above them.

No.	Part No.	Part Name	Q'ty	Price
1	TA92260	Gear Case Cover Ass'y	1 set	
2	(TP12437)	Label Rotating Direction	1	
3	TP00498	Ball Bearing 6001ZZ	2	
4	TP05502	Ring Gear	1	
5	TP05535	Thread Spindle A	1	
6	TA92387	Planetary Gear Ass'y	2 set	
7	TP06148	Spacer 22.5 x 28 x 1	1	
8	TA92616	Valve Ass'y	1 set	
9	(TP05498)	Spring Pin 2 x 16	1	
10	(TP05497)	Trigger	1	
11	(TP03592)	Filter Spring	1	
12	(TP05496)	Speed Control Nut	1	
13	(TP06147)	Valve Guide	1	
14	(TP04042)	O-Ring S-12.5	2	
15	(TP12004)	O-Ring P-10	1	
16	(TP06144)	Valve Stem	1	
17	(TP06129)	Plain Washer M3	1	
18	(TP06130)	Valve	1	
19	(TP04070)	External Retaining Ring E-2.5	1	

No.	Part No.	Part Name	Q'ty	Price
20	TP00468	Ball Bearing 608ZZ	1	
21	TP06651	End Plate B	1	
22	TA9A287	Blade Ass'y (4 pcs.)	1 set	
23	TP06142	Rotor	1	
24	TP06121	Cylinder	1	
25	TP00496	Spring Pin 2.5 x 6	1	
26	TP10109	End Plate A	1	
27	TP03933	Ball Bearing 606ZZ	1	
28	TB02956	Housing Ass'y	1 set	
29	(TQ03724)	Label Warning	1	
30	TP06175	Pin 2 x 22	1	
31	TA92620	Silencer Ass'y	1 set	
32	TQ02349	Bushing M16 x PT 3/8	1	
33	TA98285	Chuck Ass'y 6.5mm (1/4")	1 set	

ACCESSORIES

	TQ02350	Bushing PT3/8XNPT3/8	1	
	TP13643	Instruction Manual	1	